



RHINO MAINTENANCE

To insure that the Rhino Wet Waste Filtration System performs at maximum efficiency, the following maintenance program should be done on a weekly basis.

- 1. Remove clear plastic lid.**
- 2. Remove filter.**
- 3. Spray lid with cleaner/degreaser and let the lid soak. If near a sink, wash lid in sink. DO NOT use green scrub pad or stainless steel scrub pad on the clear plastic lid. This will scratch the surface. Towel or soft cloth should only be used.**
- 4. Take black plastic drain grates from the bottom of the “RHINO” and spray them with the same cleaner/degreaser. Wash in pot sink or pre –rinse**
- 5. Spray inside the “RHINO” with the cleaner/degreaser.**
- 6. Spray inside the “RHINO” with water to clean out.**
- 7. Put black drain grates back in.**
- 8. Replace filter and close clear lid.**
- 9. Repeat the following week.**

